

Agilent technical experts have compiled a list of recommended supplies that you should consider using with your new instrument in order to keep your lab operational without any disruptions and to achieve optimal performance.

## Top Supplies for Flame AAS



### Hollow cathode lamps

Select either single or multi-element coded lamps from the range available.

[See this link](#) and select lamps for the elements required.

### Sample introduction

- [9910093000](#): Nebulizer capillary kit 🏆 **(Top Recommendation)**
- [1610117390](#): Venturi for nebulizer, Mark 7, PEEK 1/pk
- [9910025700](#): Glass impact beads, 5/pk 🏆 **(Top Recommendation)**
- [9910093400](#): O-ring kit, for Mark 7 spray chamber used with aqueous samples 🏆 **(Top Recommendation)**
- [190034100](#): Mark 7 Flame Atomization System Operating Supplies Kit

## Top Supplies for Graphite Furnace AAS



### Hollow cathode lamps

Select either single or multi-element coded lamps from the range available.

[See this link](#) and select lamps for the elements required.

### Sample introduction

- [9910028200](#): Autosampler cups, 2.0 mL conical, polyethylene, 1,000/pk  
**💡 (Top Recommendation)**
- [9910115100](#): Sample capillary assembly for PSD 120, 5/pk  
**💡 (Top Recommendation)**

### Graphite furnace workhead

- [6310001200](#): Partitioned tubes, pyrolytically coated, 10/pk  
**💡 (Top Recommendation)**
- [6310003700](#): Omega platform tubes, pyrolytically coated, 10/pk
- [190067900](#): GTA 120 Deuterium furnace System Operating Supplies Kit
- [190068000](#): GTA 120 Zeeman furnace System Operating Supplies Kit